

MATCO

This Remote Application is intended to control the Internal Automation Option of any MATCO Server using an Ethernet connection on a Local Area Network.

The screenshot displays the MATCO Remote Application interface. At the top, it shows 'MATCO RSAA Version: 3 Build: 3' and 'MATCO RSAA-Level 1 Automation Remote For: Svr-1 ... MA3000 with 3 Capture and 2 Playchannels'. The 'Inv of Server:' status is 'Net OK' and the date is 'Wed Jul 26, 2006' at '01:22:41'. The main window is titled 'Server 1 Elements' and shows a list of server elements with columns for ID, Name, Duration, City, File Loc, File, and ID. The status 'ON LINE Automation Enabled' is displayed. Below this, there is a table of events with columns for Event, Type, Source, Status, Start Time, Day, Duration, ID/Location, Description, A-V, Evt Code, and Stat. The event list shows 8 events, all with a status of 'PLAY' and a duration of 02:00:00:01. The last event is 'E-Bio_Short'.

Event	Type	Source	Status	Start Time	Day	Duration	ID/Location	Description	A-V	Evt Code	Stat
1	Svr	1	PLAY			02:00:00:01	E-AB-RB7				
2	Svr	1	PLAY			00:54:28:20	E-Bio_Short				
3	Svr	1	PLAY			00:37:29:14	E-BioInformatics				
4	Svr	1	PLAY			00:00:12:00	E-BMP-Fishing				
5	Svr	1	PLAY			00:27:08:01	E-asa rv 1202				
6	Svr	1	PLAY			00:00:12:00	E-BMP-GoldWave				
7	Svr	1	PLAY			00:00:15:10	E-BMP-Melodic				
8	Svr	1	PLAY			00:54:28:20	E-Bio_Short				

It allows user to remotely:

- Create and Edit an Event Lists for the Server Automation.
- Loading and Retrieving these Lists to/from the Server.
- Appending Event Lists
- Starting and Stopping Events at the Server.
- Manually playing Server Elements and Sequences.
- Viewing Server Inventory.
- Viewing current Server Event List operation.

15000 Stetson Rd. Los Gatos, CA 95033
 Sales 800 348-1843 FAX 408-353-8781
 Support 408-353-3820

Web: www.MATCO-video.com
 Email: Sales@MATCO-video.com